



TRUCK BODIES & EQUIPMENT INTERNATIONAL, Inc.

Website: www.TBEI.com

E-mail: sales@TBEI.com

Phone: 1-800-533-0494

1-800-869-9162

036226

ELECTRIC MONARCH PUMP TRAILER INSTALLATION AND OPERATION MANUAL

To Be Filled In By Installer	
Pump Model #:	_____
Pump Serial #:	_____
Hoist Model #:	_____
In Service Date:	_____
Dealer:	_____
Address:	_____
City, State ZIP:	_____
Dealer Phone Number:	_____

Use this manual *ONLY* if installing or operating a Monarch electric pump on a TBEI TB hoist. This manual should be kept in the glove compartment of the truck pulling the trailer or any weatherproof compartment on the trailer for reference when needed.

Original Revision: June 9, 2006

Current Revision: - June 9, 2006

"INTRODUCTION"

This manual contains information necessary for the proper installation and operation of an electric power unit. This manual applies only to a Monarch unit supplied from TBEI. If you have a different power unit, refer to that manufacturer's directions. With proper installation, use, and regular maintenance, this power unit will give many years of trouble free service.

"WARNINGS"

- WARNING:** Installing or operating this hoist without first understanding the proper installation and operation procedures can lead to serious injury or death. **Always** read and understand fully all installation and operation manuals before installing or operating this equipment.
- WARNING:** Being under a raised body can result in serious injury or death should the body unexpectedly descend. **Never** position yourself or allow others to position themselves under a **loaded** body. **Always** prop the **unloaded** body up using the body prop or body props supplied. **Remember** body props are to be used only on an **unloaded** body.
- WARNING:** Malfunctioning equipment can cause property damage, injury or death. **Always** have faulty equipment repaired before continuing its use. Consult the manufacturer if required.
- WARNING:** Overloading of a trailer can cause vehicle or trailer component damage or an accident which may cause injury or death. **Never** exceed the gross vehicle weight (GVW) or the gross axle weight (GAW) rating of your vehicle or trailer.
- WARNING:** The inadvertent shorting of the vehicle's electrical supply can cause a fire or equipment damage that could lead to injury or death. **Always** disconnect the vehicle battery prior to installing, servicing, or repairing the power unit.
- WARNING:** Damage to brake lines during equipment installation, or installing bolts or equipment in such a way that the line will rub and become damaged can lead to brake failure which can cause an accident and can lead to severe injury or death. **Always** take adequate steps to prevent brake line damage during installation and isolate brake lines from installed equipment.

WARNING: Connecting the hoist to a hydraulic system with more pressure (psi) or flow (gpm) than is recommended by the hoist manufacturer can cause the hoist to fail during the dumping of a load. This could lead to damage, serious injury, or death. **Be sure** you have the correct pressure and flow. Consult the trailer manufacturer if you do not know the recommended pressure and flow.

WARNING: Adjusting the hydraulic pressure to more than the recommended setting may cause the hoist to fail during the dumping of a load. This could cause damage, serious injury, or death. **Never** adjust the pressure on your own. Consult the trailer manufacturer if the hydraulic pressure is in question. Have only a qualified person set the hydraulic pressure. **Never** adjust the pressure to more than the recommended amount.

WARNING: Fluid under pressure can pierce the skin and enter bloodstream, causing serious injury or death. **Always** wear eye protection and protective clothing when working around hydraulic systems.

"INSTALLATION INSTRUCTIONS"

POWER UNIT ATTACHMENT

The power unit should be mounted in a protected area near the hoist. For longevity of the unit and related components, do not mount near exhaust system components or in the path of road splash from the vehicle's tires.

NOTE: Mount the unit horizontally so that the reservoir is level for full use of the reservoir capacity.


WARNING: Check for potential clearance issues with vehicle brake lines, air lines, wire harnesses, etc. before determining the power units location. Avoid damage to lines or installing components that could rub against lines and cause system failures. Such failures could lead to property damage, serious injury or death.

Securely attach the pump to the frame using two 3/8"-16 x 1" flange bolts. Tighten to 33 ft.-lb. torque.

HOSE CONNECTIONS

NOTE: This manual contains descriptions of hydraulic fittings. In describing these fittings, special designations are used. These designations and their meanings are as follows:

<u>SPECIAL DESIGNATION</u>	<u>MEANING</u>
MB	Male O-Ring Boss
FB	Female O-Ring Boss
MJ	Male JIC
FJ	Female JIC



The type of fittings that are included will vary, depending on the model of hoist being installed. Refer to Figures 1a thru 1f, depending on the type of hoist and pump model that is being installed.

For all of the units, a restricted fitting is supplied. This fitting reduces the speed at which the hoist closes, to prevent damage to the trailer frame. This fitting must be installed in the base end of the hoist cylinder.


NOTE: All connections rely on O-ring or flare/face sealing methods. Therefore, no thread sealant or tape of any kind is required to seal the joints.

Leave the connection between the base end port and the hose loose at this time.

FIGURE 1a

TB-8

SINGLE-ACTING



ITEM	PART #	DESCRIPTION	QTY
1	008165	MUFFLER, 6MB, SINTERED BRONZE	1
2	008169	ADAPTER, RESTRICTED, 4MB-4MJ	1
3	03 2572	CYLINDER, 3.5X10	1
4	401825	ADAPTER, 6MB-6MJ	1
5	1200059	ADAPTER, 6MJ-6FJX90	1
6	1200070	DC POWER UNIT, ESM, 540 CI	1
7	HOSE	HOSE, 1/4", 6FJX-4FJX90, SAE 100R17	1


FIGURE 1b

TB-10

TB-12

TB-14

SINGLE-ACTING



ITEM	PART #	DESCRIPTION	QTY
1	008165	MUFFLER, 6MB, SINTERED BRONZE	1
2	008170	ADAPTER, RESTRICTED, 6MB-6MJ	1
3	401825	ADAPTER, 6MB-6MJ	1
4	1200059	ADAPTER, 6MJ-6FJX90	2
5	1200070	DC POWER UNIT, ESM, 540 CI	1
6	CYLINDER	CYLINDER, HOIST	1
7	HOSE	HOSE, 1/4", 6FJX-6FJX, SAE 100R17	1


FIGURE 1c

TB-16

TB-18

TB-20

SINGLE-ACTING




ITEM	PART #	DESCRIPTION	QTY
1	008165	MUFFLER, 6MB, SINTERED BRONZE	1
2	008171	ADAPTER, RESTRICTED, 8MB-6MJ	1
3	401825	ADAPTER, 6MB-6MJ	1
4	1200059	ADAPTER, 6MJ-6FJX90	1
5	1200071	DC POWER UNIT, ESM, 1039 CI	1
6	CYLINDER	CYLINDER, HOIST	1
7	HOSE	HOSE, 3/8", 6FJX-6FJX, SAE 100R17	1

FIGURE 1d

TB-8

DOUBLE-ACTING



ITEM	PART #	DESCRIPTION	QTY
1	008169	ADAPTER, RESTRICTED, 4MB-4MJ	1
2	03 2572	CYLINDER, 3.5X10	1
3	401825	ADAPTER, 6MB-6MJ	3
4	1200059	ADAPTER, 6MJ-6FJX90	3
5	1200097	DC POWER UNIT, EDM, 540 CI	1
6	HOSE	HOSE, 1/4", 6FJX-6FJX, SAE100R17	1
7	HOSE	HOSE, 1/4", 6FJX-4FJX90, SAE 100R17	1


FIGURE 1e

TB-10

TB-12

TB-14

DOUBLE-ACTING



ITEM	PART #	DESCRIPTION	QTY
1	008170	ADAPTER, RESTRICTED, 6MB-6MJ	1
2	401825	ADAPTER, 6MB-6MJ	3
3	1200059	ADAPTER, 6MJ-6FJX90	3
4	1200097	DC POWER UNIT, EDM, 540 CI	1
5	CYLINDER	CYLINDER, HOIST	1
6	HOSE	HOSE, 1/4", 6FJX-6FJX, SAE100R17	1
7	HOSE	HOSE, 1/4", 6FJX-6FJX, SAE100R17	1


FIGURE 1f

TB-16

TB-18

TB-20

DOUBLE-ACTING



ITEM	PART #	DESCRIPTION	QTY
1	008171	ADAPTER, RESTRICTED, 8MB-6MJ	1
2	401825	ADAPTER, 6MB-6MJ	3
3	1200059	ADAPTER, 6MJ-6FJX90	3
4	1200097	DC POWER UNIT, EDM, 540 CI	1
5	CYLINDER	CYLINDER, HOIST	1
6	HOSE	HOSE, 3/8", 6FJX-6FJX, SAE100R17	1
7	HOSE	HOSE, 1/4", 6FJX-6FJX, SAE100R17	1

INSTALL ELECTRICAL

1. Route a copper American Wire Gage (AWG) #00 cable from the battery to the power unit. Connect one end to the negative battery terminal. Connect the other end to the power unit's aluminum valve block with a 5/16"-18 x 3/4" hex cap screw as shown in Fig. 3.

CAUTION: The high current demands of the power unit require a direct connection between the negative post of the battery and the power unit. Never rely on the vehicle's grounding circuit, which could lead to property damage or reduced hoist lifting capacity during peak loads.

NOTE: Avoid routing locations where power cables may rub against any sharp edges of the vehicle, get pinched or be exposed to excessive heat. Install approved sheathing over each cable in critical areas.

2. Route a copper AWG #00 cable from the battery to the power unit. At the power unit, insert the supplied rubber terminal boot over the end of the cable and the black wire as shown in Fig. 2. Fasten the cable end and black wire to "Point A" on the solenoid start switch. Tighten to 35 in.-lb. torque. Snap rubber terminal boot over stud to complete connection. Make sure all connections on solenoid start switch are secure. Do not connect the cable to the battery at this time to prevent a dry start.



WARNING: Never tighten battery cable stud, marked "Point A", to more than 35 in.-lb. torque and never tighten control stud, marked "Point B", to more than 15 in.-lb. torque. Exceeding torque rating for either stud can cause unit to malfunction, which could lead to property damage, serious injury or death.

3. (Double-Acting only) Place the solenoid cover over the solenoid and secure in place with the tie strap provided.

4. The hoist should only be used with the operator in a safe location. Locate the hoist control station in a safe location.



FIGURES 2a & 3a

SINGLE-ACTING SCHEMATICS



FIGURES 2b & 3b

DOUBLE-ACTING SCHEMATICS



FILL & PRIME

Fill the reservoir with automatic transmission fluid (ATF), such as Dexron® II Type A. Secure the unit's power cable to the positive battery terminal to complete the electrical installation and allow operation of the unit. Place a drip pan or other suitable container below loose hose fitting at base end of cylinder. Press "UP" pushbutton on control station to begin priming the unit. Once oil begins flowing steadily from loose fitting, release pushbutton. Tighten fitting. Operate unit several times starting with short cylinder strokes and increasing length with each successive stroke. Recheck oil level often and add as necessary to keep pump from picking up air. After hoist has been fully raised and lowered repeatedly to purge air from cylinder, lower hoist and check oil level in reservoir. With the hoist down, the reservoir should be full within 2" of the top. **DO NOT OVERFILL!** Install filler/breather cap in reservoir fill hole.

“OPERATION INSTRUCTIONS”

WARNING: Being under or near a raised body can result in injury or death should the body unexpectedly descend or tip. Hoist must be activated with operator in control at a safe location. No one must be allowed to enter the area under a raised body while the hoist is in operation.

WARNING: Being under a raised body can result in serious injury or death should the body unexpectedly descend. **Never** position yourself or allow others to position themselves under a **loaded** body. **Always** prop the **unloaded** body up using the body prop or body props supplied. **Remember** body props are to be used only on an **unloaded** body.

DANGER:

1. Stay out from under body when hoist is operating.
2. During dumping operations, no one must be allowed to stand in or move through the area where the body and hoist operate or into an area where an upset load might fall.
3. Controls must be in a safe location and operator must remain at controls during the dumping operation. Controls must be located in a location where it is not possible to be under body during dumping operation.
4. **Never** leave body raised or partly raised while the trailer is unattended or while performing maintenance or service under body, unless body is braced to prevent accidental lowering.
5. **Do not** attempt to raise a loaded body when the truck or trailer is on un-level ground.
6. Never jerk or shock a raised body to loosen a stuck load.

WARNING: Freeing a stuck load during dumping, with the body raised, by jerking or shocking the trailer, may cause damage to the trailer, serious injury or death. **Never** drive forward or rearward and stop quickly with the load up or otherwise shock the load. If a load is stuck in the body, lower the body, then free the load.

WARNING: Attempting to dump a load on un-level ground may cause the trailer to over turn, and can result in damage, serious injury or death. **Always** dump the load on ground that is level front to rear as well as level side to side.

WARNING: Overloading a hoist can cause component damage or an accident which may cause injury or death. **Never** exceed the hoist’s rated lift capacity.

WARNING: Damaged or malfunctioning equipment may cause injury or death. Repair or replace any damaged or malfunctioning equipment before continuing its use.

NOTE: Always use clean automatic transmission fluid (ATF) in the power unit. Do not mix types. Check oil level often and add as needed to prevent unit from pumping air. Change fluid annually to remove condensation and entrapped debris.

NOTE: Grease the hoist at regular intervals, at least every time the vehicle is serviced. See Hoist Owner’s Manual for specific details and locations.

SINGLE-ACTING

Raise the hoist by pressing and holding the “UP” pushbutton on the control station. This activates the power unit and directs oil to the base end of the hoist cylinder. Releasing the pushbutton will stop raising the hoist and it will hold its position.

NOTE: The power unit is equipped with a factory-set hydraulic relief valve that will bypass at 3200 PSI when the hoist reaches a fully raised position or whenever the load being lifted exceeds the hoist capacity. Care should be taken not to let the pump bypass for long periods of time, as this will put stress on the whole hydraulic and electrical system. To stop the pump from bypassing, release the “UP” button on the control station.

Lower the hoist by pressing and holding the “DOWN” pushbutton on the control station. This activates the solenoid valve and directs oil from the cylinder back to the power unit’s reservoir. Releasing the pushbutton will stop lowering the hoist and it will hold its position.

DOUBLE-ACTING

Raise the hoist by pressing and holding the “UP” pushbutton on the control station. This activates the power unit and directs oil to the base end of the hoist cylinder. Releasing the pushbutton will stop raising the hoist and it will hold its position.

NOTE: The power unit is equipped with a factory-set hydraulic relief valve that will bypass at 3200 PSI when the hoist reaches a fully raised position or whenever the load being lifted exceeds the hoist capacity. Care should be taken not to let the pump bypass for long periods of time, as this will put stress on the whole hydraulic and electrical system. To stop the pump from bypassing, release the “UP” button on the control station.

Lower the hoist by pressing and holding the “DOWN” pushbutton on the control station. This will activate the pump and start the hoist down. Releasing the pushbutton will stop lowering the hoist and it will hold its position.

NOTE: When the hoist reaches its “DOWN” limit, the pump will bypass. Care should be taken not to let the pump bypass for long periods of time, as this will put stress on the whole hydraulic and electrical system. To stop the pump from bypassing, release the “DOWN” button on the control station.